

SOP - Acoustic Online Measurements

Version 2, 20200415.

Pre-requirements: calibrated chamber (mics and speakers), see separate document

- A. connect DUT1 power and ethernet cable 1st side into DUT1
- B. screw DUT 1 holder
- C. place DUT1 ethernet 2nd side into switch (there may only be 1 DUT connected at any time)
- D. place DUT1 into chamber
- E. start SoundCheck script
- F. push the two close door buttons until OBO signal that door is closed and operator can work on other tasks*

(Target: Step 1-12 <45 seconds)

- 1. connect DUT2 power and DUT2 side of ethernet
- 2. screw DUT2 holder
- 3. wait until SC tell you to continue SOP
- 4. remove DUT1 ethernet cable from switch and place DUT2 eth 2nd side into switch (this i done before door is open)
- 5. Remove DUT1 from chamber
- 6. In UI (DUT1) touch enter=pass or esc =fail, before unplugging power
- 7. pull power cord from DUT1
- 8. place DUT2 in chamber
- 9. Start SC script (for DUT2). (OBO: here and during closing door, the initial part of the sequence and the slider move will all run in parallel)
- 10. push the two close door buttons until measurement sequence starts
- 11. unscrew DUT1 holder
- 12. goto 1 (DUT3)